

Libre Tea - Glass'n Poly Care and Use

Note: Please hand wash and do not use in microwave Please watch <u>'how to use video'</u> on www.libretea.com

Q. What do I do if I have a Libre glass'n poly tea glass that leaks?

- 1. Please check to ensure that rubber seals are in place in both the filter connector and the lid.
- 2. Please ensure there are no tea leaves on the threads where the pieces twist together and that these surfaces are dry tea bits and water bubbles can compromise the seal.
- 3. Once seals are confirmed to be in place and threads are dry and clean, please try refilling and turning upside down gently over the sink to re-test. If your tea glass is still leaking please write us at info@libretea.com and describe where the leakage is coming from and we will ensure it is fixed or replaced for you to keep on enjoying tea moments.

With Libre tea glasses, drinking loose leaf tea at home or on-the-go couldn't be easier!

Method #1: Remove lid and tea filter, add 2-3 grams of loose- leaf tea to the glass. Replace filter, add hot water and allow the tea to steep. Enjoy!

ALWAYS USE CAUTION WITH BOILING WATER – ALLOW COOLING TIME FOR STEAM TO DISSIPATE PRIOR TO TWISTING ON LID - STEAM PRESSURE MAY CAUSE LEAKS

Method #2: The Libre Glass 'n Poly model can also be used for teas with limited steeping times:

Step 1:



Remove the lid and filter; carefully add hot water to below the rim of the tea glass.

Twist the filter on securely; add 2 -3 grams of loose- leaf tea on top of the filter.

Step 2:



Wait 2-3 minutes prior to twisting on lid so steam pressure does not force a leak upon inverting.

After the brief cool down period, twist on the lid securely and slowly turn the glass upside down to steep the tea.

Step 3:



Release the lid slightly, then the filter to ensure all tea releases into the glass and does not remain in the filter section. Enjoy!

(Note: spent tea leaves remain in the filter and can be reused)